



## UPUTUSKRAE

- 💧 Aseta uputuskrae plaadid soovitavale kohale laudisel. Jälgi, et uputuskrae otsmised servad oleksid seina vastas.
- 💧 Märgi lavalaudisele uputuskrae siseserv.
- 💧 Järgi märgitud joont ja tömba 52 mm väljapoole teine kontuur. Soovitame selleks kasutada 52 mm laiust puitklotsi.
- 💧 Lõika ava järgides laiem kontuur.
- 💧 Monteeri uputuskrae kronsteinid plaatide külge kasutades polti ja mutrit.
- 💧 Paigalda uputuskrae lõigatud avasse, vajadusel kohenda lõikeserva.
- 💧 Kinnita kronsteinid kruvidega lavalaudade külge.
- 💧 Nüüd võid paigaldada DROP kerise. Järgi miinimumkõrgust alolevast joonisest:

## EMBEDDING FLANGE

- 💧 Place the plates of embedding flange on the desired place of the boarding. Make sure that the end edges of the embedding flange are against the wall.
- 💧 Mark the inner edge of the embedding flange on the boarding of the sauna platform.
- 💧 Follow the marked line and draw the second contour 52 mm outwards. We recommend using a 52 mm wide wooden block for that purpose.
- 💧 Cut the wider contour by following the aperture.
- 💧 Attach the brackets of the embedding flange to the plates by using bolts and nuts.
- 💧 Install the embedding flange to the cut aperture, adjust the cut edge, if necessary.
- 💧 Attach the brackets to the boards of the platform with screws.
- 💧 You can now install the DROP heater. Follow the minimum height from the figure below:

